




BARRIERA AUTOMATICA
AUTOMATIC BARRIER
BARRIÈRE AUTOMATIQUE
AUTOMATISCHE SCHRANKE
BARRERA AUTOMÁTICA



ISTRUZIONI D'USO E DI INSTALLAZIONE
INSTALLATION AND USER'S MANUAL
INSTRUCTIONS D'UTILISATION ET D'INSTALLATION
INSTALLATIONS-UND GEBRAUCHSANLEITUNG
INSTRUCCIONES DE USO Y DE INSTALACION

MAXIMA ULTRA 68

Bft

D812171 00550_06 16-05-17

Attenzione! Leggere attentamente le "Avvertenze" all'interno! **Caution!** Read "Warnings" inside carefully! **Attention!** Veuillez lire attentivement les Avertissements qui se trouvent à l'intérieur!
Achtung! Bitte lesen Sie aufmerksam die „Hinweise“ im Inneren! **Atención!** Leer atentamente las "Advertencias" en el interior! **Let op!** Lees de "Waarschuwingen" aan de binnenkant zorgvuldig!



Index

1. General information

- 1.1 Introduction..... pag.10
- 1.2 General safety..... pag.10
- 1.3 General..... pag.10
- 1.4 Technical specification pag.10
- 1.5 Overall dimensions..... pag.11

2. Installation

- 2.1 Cable note..... pag.11
- 2.2 Fixing the structure..... pag.11
- 2.3 Springs mounting pag.12
- 2.4 Instal the arm pag.13

- 2.5 Align the arm..... pag.13
- 2.6 Balancing the arm..... pag.14
- 2.7 Optionals pag.14
- 2.8 Electrical connections..... pag.14

3. Use and maintenance

- 3.1 General safety..... pag.15
- 3.2 Warnings..... pag.15
- 3.3 Use pag.15
- 3.4 Manual manoeuvre pag.15
- 3.5 Routine maintenance pag.15

1.1 INTRODUCTION



Please read it carefully before installing the appliance, before using it and before routine or extraordinary maintenance work.



The notices preceded by this symbol provide important information, the non-compliance with such instructions voids the manufacturer's guarantee.

OPERATIONS THAT, IF NOT CARRIED OUT CORRECTLY, CAN BE RISKY, ARE INDICATED WITH THE FOLLOWING SYMBOLS



ELECTROCUTION



CRUSHING

The INSTALLATION, USE AND MAINTENANCE handbook is for installers, users and maintenance engineers

The Company is not liable for injury to people or animals or damage to things in the case of applications that exceed the limits specified on the enclosed technical data sheet or by a use different from what the appliance has been designed.

Warning! Observe all the instructions, improper installation can result in serious injury.

1.2 GENERAL SAFETY

- Scrap packing materials (plastic, cardboard, polystyrene etc) according to the provisions set out by current standards. Keep nylon or polystyrene bags out of children's reach.
- Disconnect the electrical power supply before carrying out any work on the installation. Also disconnect any buffer batteries, if fitted.
- Fit an omnipolar or magnetothermal switch on the mains power supply, having a contact opening distance equal to or greater than 3,5 mm.
- Check that a differential switch with a 0,03A threshold is fitted just before the power supply mains.
- The outputs are not of type SELV (separated extra-low voltage), therefore it must not be possible to reach them.
- Fit all the safety devices (photocells, electric edges etc.) which are needed to protect the area from any danger caused by squashing, conveying and shearing, according to and in compliance with the applicable directives and technical standards.
- The Company declines all responsibility with respect to the automation safety and correct operation when other manufacturer's components are used.
- Only use original parts for any maintenance or repair operation.
- Do not modify the automation components, unless explicitly authorised by the Company.
- Instruct the product user about the control systems provided and the manual opening operation in case of emergency.
- Do not allow persons or children to remain in the automation operation area.
- Keep radio control or other control devices out of children's reach, in order to avoid unintentional automation activation.
- Do not allow children to play with the equipment.
- The equipment may be used by children aged over 8 years old and by people with reduced physical, sensory or mental capabilities, or without experience or the necessary knowledge, provided they are supervised or after they have received instructions relating to the safe use of the equipment and have understood the dangers inherent in it.
- Cleaning and maintenance meant to be performed by the user must not be performed by unsupervised children.
- Anything which is not expressly provided for in the present instructions, is not allowed.

1.3 GENERAL

The automatic electromechanical barrier is designed to control passage openings up to 8 metres wide, for a maximum torque applicable to the bar shaft of 1150 Nm, in compliance with European standards. It is suitable for industrial applications and it is the ideal solution for managing vehicle traffic.


1.4 TECHNICAL SPECIFICATIONS

Power.....**230Vac/115Vac ±10% 50/60Hz**
 Motor.....**230Vac 900RPM 14uF 0.5kW**
 Absorbed power.....**650W**
 Control unit.....**CSB-Xtreme**
 Impact safety.....Encoder

Opening time.....**4.5 ÷ 6.0 s ****
 Arm length.....**4 ÷ 8 m**
 Working temp.....**-30*** +60°C**
 Manoeuvres in 24h.....**3 000**
 Protection level.....**IP 54**

Net weight.....**95 kg**
 Gross weight.....**98 kg**
 Sound pressure level.....**LpA≤70 dB (A)**
 ** the opening times are considered from closed bar to slow down start
 *** With integrated heater active


1.5 OVERALL DIMENSIONS



2.1 CABLE NOTE




- | | |
|--------------------------|-------------|
| 1) Single-phase line | 2 x 1,5 + E |
| 2) Transmitter photocell | 2 x 0,5 |
| 3) Receiver photocell | 4 x 0,5 |
| 4) Flashing light | 2 x 0,5 |
| 5) Key selector | 3 x 0,5 |
| 6) Receiver | 4 x 0,5 |
| 6) Antenna | RG58 |
| 7) Magnetic coil | |




ENGLISH

2.2 FIXING THE STRUCTURE







2.3 SPRINGS MOUNTING



! If single spring, mount in position 1





First mount spring 2 if present.

ENGLISH




Do not tighten before the balancing arm (see point 2.6)

Mount spring 1.



Do not tighten before the balancing arm (see point 2.6)

2.4 INSTALL THE ARM




ENGLISH

2.5 ALIGN THE ARM



Electrically connect the control unit (see point 2.8)



"START"




- Insert about 1 metre of the arm in the holder
- Give the "START" command to position the arm holder horizontally
- Pull the arm down to help the reducer counteract the force of the pre-calibrated spring


Install the arm and adjust the holder





USE THE ADJUSTABLE ARM HOLDER TO ALIGN THE ARM WITH THE ROAD.





Check that the bar is in horizontal position




Give the "START" command to position the arm holder vertically




Check that the bar is in vertical position




2.6 BALANCING THE ARM



Put the bar in a vertical position.




For the "A" value see **TAB.1** page 34



Check that the arm is balanced at ~45°


2.7 OPTIONALS



2.8 ELECTRICAL CONNECTIONS

CSB-Xtreme

Consult the control unit's installation and operating manual



3.1 GENERAL SAFETY

- The barrier is designed exclusively for vehicles traffic; report and delimit any walkways through a special sign.
- Keep adults, children and property out of range of the automated system, especially while it is operating.
- For safety reasons and to comply with current standards, we recommend using the control unit.
- To install follow the instructions given in the enclosed "GENERAL INSTRUCTIONS FOR SAFETY" sheet.
- All electrical connections must be done in compliance with current laws.
- The installer must instruct the user on how to use the automatism correctly, on the manual emergency manoeuvre and on the possible risks during operation.
- Analyse the risks and take all the appropriate measures to eliminate them, as prescribed by the **EEC** machine directive **2006/42**, installing the safety devices.
- Always disconnect the electricity before attempting any work on the system with a lockable cut-off switch.
- Cleaning and maintenance meant to be performed by the user must not be performed by unsupervised children

3.2 WARNINGS

Correct controller operation is only ensured when the data contained in the present manual are observed. The Company is not to be held responsible for any damage resulting from failure to observe the installation standards and the instructions contained in the present manual.

The descriptions and illustrations contained in the present manual are not binding. The Company reserves the right to make any alterations deemed appropriate for the technical, manufacturing and commercial improvement of the product, while leaving the essential product features unchanged, at any time and without undertaking to update the present publication.

3.3 USE




- It is essential to follow the instructions given in the enclosed "GENERAL INSTRUCTIONS FOR SAFETY" sheet.
- **In the case of a manual emergency manoeuvre, follow the indications described in point 3.4.**
- Consult the control unit's installation and operating manual.

3.4 MANUAL MANOEUVRE

Always disconnect the electricity before attempting any work on the system

Releasing the barrier

WITH MOUNTED BOOM ONLY



3.5 ROUTINE MAINTENANCE (EVERY 6 MONTHS)

- Maintenance must be carried out by qualified personnel only.
- Check the condition of the barrier structure.
- Check tightness of the arm.
- Check the condition of the spring, chain and relative anchorings.
- Check arm balance.
- Check that at the end of travel the arm is horizontal and/or vertical
- Check operation of the control unit and safety devices.
- Check operation of the manual emergency manoeuvre.
- Record maintenance in the form on the page 35.

REGISTRO DI MANUTENZIONE
MAINTENANCE LOG

Dati impianto • Installation data

Installatore <i>Installer</i>	
Cliente <i>Customer</i>	
Matricola <i>Serial number</i>	
Data installazione <i>Installation date</i>	
Data attivazione <i>Activation date</i>	
Luogo <i>Location</i>	

Nr.	Data • Date	Descrizione intervento • Intervention description	Firma • Signature
1			Tecnico • Technician
			Cliente • Customer
2			Tecnico • Technician
			Cliente • Customer
3			Tecnico • Technician
			Cliente • Customer
4			Tecnico • Technician
			Cliente • Customer
5			Tecnico • Technician
			Cliente • Customer
6			Tecnico • Technician
			Cliente • Customer
7			Tecnico • Technician
			Cliente • Customer
8			Tecnico • Technician
			Cliente • Customer
9			Tecnico • Technician
			Cliente • Customer

INSTALLATORE
INSTALLER
INSTALLATEUR
INSTALLATEUR
INSTALATOR

DATA
DATE
DATE
DATUM
FECHA

Bft Spa

Via Lago di Vico, 44 ITALY
36015 Schio (VI)
T +39 0445 69 65 11
F +39 0445 69 65 22



SPAIN

**BFT GROUP ITALIBERICA DE
AUTOMATISMOS S.L.**
08401 Granollers - (Barcelona)

FRANCE

AUTOMATISMES BFT FRANCE
69800 Saint Priest

GERMANY

BFT TORANTRIEBSSYSTEME GmbH
90522 Oberasbach

UNITED KINGDOM

BFT AUTOMATION UK LTD
Heaton Mersey, Stockport SK4 3GL

IRELAND

BFT AUTOMATION LTD
Dublin 12

BENELUX

BFT BENELUX SA
1400 Nivelles

POLAND

BFT POLSKA SP. Z O.O.
05-091 ZĄBKI

CROATIA

BFT ADRIA D.O.O.
51218 Drazice (Rijeka)

PORTUGAL

**BFT SA-COMERCIO DE
AUTOMATISMOS E MATERIAL DE
SEGURANCIA**
3026-901 Coimbra

CZECH REPUBLIC

BFT CZ S.R.O.
Praha

TURKEY

**BFT OTOMATIK KAPI SISTEMELERI
SANAY VE**
Istanbul

RUSSIA

BFT RUSSIA
111020 Moscow

AUSTRALIA

**BFT AUTOMATION AUSTRALIA
PTY LTD**
Wetherill Park (Sydney)

U.S.A.

BFT USA
Boca Raton

CHINA

BFT CHINA
Shanghai 200072

UAE

BFT Middle East FZCO
Dubai